Side view

Back view

Paper Bin

Camera And

SAM Card

Slot

Flash

Opener

NFC Read

Area

Loudspeaker

Battery Cover

Micro SD

Card Slot

SIM Card


Slot

Lock

Ø 000

Lithium-ion Battery Instructions And Notes

Customer Instruction



- above 45 degree Celsius). 3. The battery should only be using by the power adaptor or cradle
- provided with the product. 4. To store the device, remove the battery from the device and store
- separately. Do not store device with battery installed. 5. Charge and discharge battery every 3 month during storage. Optimal battery charge for storage is 60%-70%.
- 6. Battery should be stored in a cool, dry and well-ventilated environment, Urovo recommends battery storage at 20 °C ~ 40 °C / 65±20%RH environment.

Transport Precautions

- 1.Do not transport the battery at ambient temperature higher than 65 $^{\circ}\mathrm{C}$.
- 2.Please keep device and battery separately during storage
- 3. Pack with battery with appropriate packing materials.

Precautions

- 1. Do not expose battery into a fire or heat source;
- 2. Do not short the battery
- 3. Do not intentionally drop or put battery in violent mechanical motion
- 4. Do not immerse battery in water or store it in humid environment.
- 5. Do not tampered with charger or use charger that is suspected to be tampered with
- 6. If battery appears to be discolored, swollen, unusually hot, remove battery from the device immediately and dispose appropriately.
- 7. Battery is consumable product. Battery capacity will decrease over time. Replace battery between one or two years.
- 8. When there is any accident and emergency pertaining battery usage, please contact Urovo on time and provide the relevant information such as photographs and operation environment.

Disclaimer

UROVO is not responsible for users' personal and property safety under the following circumstances

- 1. Abusive and inappropriate usage.
- 2.Using unqualified logistic services to transport the battery.
- 3.Battery not purchased from official Urovo sales channel.

Appearance and Buttons

Front View



Sleep: manually by pressing the power button or set up the system after the sleep can trigger sleep mode.

Wake up: When the display is off, press power button once to turn on the

Cold-start: press "Fn", then click reset button.

Note: Please turn off the device before storage to prevent the battery to be completely drained during storage.

















19000S Handheld Payment **Terminal User Guide**

Insert the battery into the battery compartment. Battery should sit tightly in the compartment when correctly installed. Do not use excessive force to insert the battery.





Close the cover and fix the battery cover lock.

Battery Operation



Charge the battery only with original power adaptor.

Do not short the battery. Do not store battery in hot, humid, or corrosive environment. Do not subject battery to abusive mechanical impact.

Do not store battery when it is fully charged or completely drained. If device is not used for a long time, remove the battery from the device.

Battery Charging



USB Data Cable

Power Adaptor

Charge By USB Data Cable

Connect the device through the USB data cable to connect the power supply equipment such as the PC, the mobile power supply and so on. The state of the indicator lamp is consistent with the adapter charging.

Charge By DC Power Adaptor

Plug in the power adaptor connector into the DC power port on the terminal device. Red color LED at top left corner indicates at battery is charging. Green LED indicates battery is fully charged.

Installing the SIM/TF Card



Insert the SIM/TF Card into their corresponding slots in the battery compartment.

Installing TF Card is similar to SIM Card.

- 1.Standard SIM Card is required.
- 2. You should gently push the SIM/TF card to the correct position without using excessive force.
- 3.To remove the TF card, press the exposed part of the TF Card inward, and the card will be ejected from the slot. Do not use excessive force.

Installing Printing Paper

- 1. Open the paper bin cover and install the paper as below picture showing.
- 2.Close the paper cover with a click.
- 3. Tear of the exposed paper quickly to ensure the incision is smooth.





Magnetic Stripe Card Swipe **Operating Instructions**

- 1. Hold on the device and bank card:
- 2. Swipe the IC card smoothly with the magnetic strip toward inside;





Contact IC Card Instructions

Insert IC card into the device gently with metal contact upward. Please do not use excessive force so as not to damage the IC card or device.





Non-contact IC Card Instructions

To read non-contact card, place card near the NFC antenna, as shown below:



Computer On-line Instructions

When you personal computer installed android system drivers, you can connect device and personal computers through a USB data cable (you can obtain these software from our technical support team).

Once you have installed the required software driver, insert USB cable into the device and the computer's USB port, and you will see the device screen as shown in the figure.



Tap the top of the screen. drag downwards and the USB setting interface will appear.



Click on this to go the next

Lets you transfer media files on Windows, or using Android File Transfer on Mac (see www.android.com/filetransfer)

Lets you transfer photos using camera software, and transfer any files on computers that don't support MTP


left interface

left interface

USB computer connection

Media device (MTP)

Mount SD card



you intend to develop

software and step through

your code with the device.

- Check the SD Card option if you intend to transfer files between your PC and the device.

Note: the contents of this manual are subject to change without prior notice.